

Attach the fibreglass panelling - this should be done carefully using the instructions provided. Fit them once to make sure everything is drilled and bolted properly and then remove them to enable painting of the body and panels - best carried out separately.

Paint can then be applied and the panels refitted using beaded jointing to protect and enhance the appearance.

### Phase 3

Fit the dash, refit the wiring harness

Refit the pedal assembly, steering column, clutch and accelerator components

Trim the body tub

Fix the windscreen, hardwood door hinge supports and fix doors

Fit seat belts and handbrake assembly

Trim the bonnet to fit the opening, connect up brakes, petrol tank, radiator fixings and other smaller items and bingo - another Tempest is born!